



Your product shall have the following **contents**:

- 1x **SATCOM** antenna
- 2x **ADF** antennas
- 2x **ELT** antennas
- 3x **drain mast**
- 4x **VHF** antenna
- 4x **TCAS** antenna

**Instructions:**

1. Remove the two blocks in front and behind the antenna using a resin saw or a side cutter. Leave the antenna attached to the base.
2. When working with resin, it is important to apply a resin suitable primer and to prime the entire part. You can tape the base to a piece of cardboard during painting.
3. Once the primer has dried, apply your desired color, most likely white.
4. Apply a protective clear coat.
5. Use tweezers to hold the antenna while carefully cutting the thin supports to separate the antenna from the base.
6. Use PVA glue to attach the antennas to the painted, polished and clear coated fuselage.
7. Remove excess glue and you're **done!**

**Bonus tip:** Use airport planning manuals published by aircraft manufacturer to get the exact location of each antenna or drain mast.

**Color recommendation:**

Color	Gunze	MRP	Revell Aqua	Tamiya
gloss white	1	004	04	X2