



Your product shall have the following **contents**:

- two **3D printed fans**
- paint mask on **TAMIYA** sheet

**Instructions:**

1. Remove the outer railing which protects the fans using a resin saw or a side cutter.
2. Remove all 18 outer blade supports using a side cutter. Be careful not to break off blades.
3. Remove all 18 inner blade supports using a side cutter.
4. Remove the remaining 4 supports at the wheel hub assembly in the very center of the fan. Be careful not to break off the pin in the center or any blades.
5. With the fan now detached from the support structure, turn it upside down and remove the burr.
6. Use the pin in the center to hold it during painting. When working with resin, it is important to apply a resin suitable primer and to prime the entire part.
7. Once the primer has dried, apply titanium paint.
8. Apply the paint masks to each individual blade and mask off the leading edges.
9. Paint the blades using a black, semi gloss paint.
10. Remove the paint masks, apply the spinner decal included in the Zvezda kit and you're **done!**

**Color recommendation:**

Color	Gunze	MRP	Revell Aqua	Tamiya
semi gloss black	92	005	302	XF01
Titanium	SM205	082	91	X32