



Your product shall have the following **contents**:

- two **wheel spruces**
- two **rim spruces**
- four **brake assembly spruces**

**ATTENTION:**

The holes on both sides of the wheels have different depths! Look at the embossed text on the spruce, the side with "MAIN AND NOSE TIRES FOR 787-9" has the deeper holes.

**Instructions:**

1. Identify the side with deeper holes, if you receive wheels broken off from the spruce you can compare them with ones still attached and then determine which side has the deeper hole.
2. Remove all the parts from their spruces using a resin saw. Be careful not to break the brake actuation rod from the brake assemblies.
3. Clean off the parts using a file and sanding sponges
4. If desired, rescribe the tire tread with a resin saw.
5. When working with resin, it is important to apply a resin suitable primer and to prime the entire part. Prime all the parts separately from each other.
6. Paint the tires in a typical rubber color.
7. Paint the rims and brake assemblies in light grey.
8. Paint the brake actuation rod in semi gloss black.
9. Use CA glue (super glue) to glue all the parts together. The rims go into the deeper hole, the brake assemblies go into the more shallow one.
10. Use CA glue (super glue) to attach the wheel assemblies to the gear strut and you're **done!**

**Color recommendation:**

Color	Gunze	MRP	Revell Aqua	Tamiya
rubber	137	173	09	XF85
light grey	338	363	371	XF80
semi gloss black	92	005	302	XF01